Photo Sport II series

Photo Sport BP 200 AW II Photo Sport BP 300 AW II

Two passions. One pack.

This next-generation of our Photo Sport is built for photographer-adventurers who like to go fast and light with their gear. Designed to protect your photo gear in the UltraCinch™ chamber, and all of your journey's essentials in the open space.

Lightweight, weather-resistant materials and a built-in All Weather AW Cover™ keep you moving when the weather changes.

The side-access UltraCinch™ chamber allows you to tighten the camera compartment from outside of the pack to stabilize gear while you are in motion.







Photo Sport II series

Photo Sport BP 200 AW II Photo Sport BP 300 AW II

- Keep your camera gear secure and in place while you're in motion. Our new UltraCinch™ design (think 2.0) features a custom pull-tab to cinch and tighten photo gear space in one swift action.
- Feel good as you run, hike, bike, climb, board or trek with the ActivZone[™] harness – built to provide targeted comfort for active shooters.
- Lighten up! The next-generation pack build offers overall lighter weight for easy carry and true portability when engaged in aerobic sports or activities.
- A built-in All Weather AW Cover[™] provides protection from the elements when needed.

Materials: N100 nylon with UTS coating, N210D HD Oxford nylon, stretch polyester

Photo Sport BP II 200 AW shown on right







Photo Sport BP 200 AW II

- DSLR with attached lens (such as Canon Rebel T5i with 18-135mm f/3/5-5.6, OR Sony A7II with 24-70 attached)
- Flash, adapter or extra lens
- 2-liter hydration reservoir (not included)
- Extra gear such as bike helmet, jacket, snacks, sunglasses, compact tripod, etc.

Exterior Dimensions (WxDxH)

9.6 x 7.7 x 20.5 in. 24.5 x 19.5 x 52.0 cm

Interior Dimensions (WxDxH)

6.3 x 3.5 x 8.1 in. 16.0 x 9.0 x 20.7 cm

Total Weight

2.7 lbs. | 1.2 kg







UltraCinch™ ActivZone™ AWCover™



Find out more at lowepro.com





Roomy, toploading compartment for creature comforts

Multiple attachment points for tripod, hiking poles, etc.

Front pocket fits a bike helmet, light jacket, gloves, etc.

Stabilizing waist strap includes two zippered side pockets for quick-grab items

Photo Sport BP 300 AW II

• Up to Pro DSLR with attached lens (such as Canon 5D with 24-70mm f/2.8)

• Up to 2 extra lenses (such as 24-102mm and 70-200mm)

- Flash
- · 2-liter hydration reservoir (not included)
- Extra gear such as bike helmet, jacket, snacks, sunglasses, compact tripod, etc.

Exterior Dimensions (WxDxH)

10.6 x 9.4 x 22.0 in. 27.0 x 24.0 x 56.0 cm

Interior Dimensions (WxDxH)

8.3 x 3.5 x 8.8 in. 21.0 x 9.0 x 22.3 cm

Total Weight

3.2 lbs. | 1.5 kg







Ultra**Cinch**™ Activ**Zone**™

AWCover™



Available Colors: Black and Horizon Blue Models may vary by locations.

Find out more at lowepro.com





Roomy, toploading compartment for creature comforts

Multiple attachment points for tripod, hiking poles, etc.

Front pocket fits a bike helmet, light jacket, gloves, etc.

Stabilizing waist strap includes two zippered side pockets for quick-grab items

Photo Sport II series

Photo Sport BP 200 AW II Photo Sport BP 300 AW II



Updated UltraCinch™ side opening with a custom pull-tab system lets you fit your camera kit snugly inside a dedicated compartment for bounce-free protection.



Get extra padding in all the right spots, thanks to the ActivZone™ harness system, padded waistbelt and comfortable, adjustable shoulder straps.



A built-in All Weather AW Cover™ may be deployed to cover pack and protect gear from rain, snow, dust or sand.



Keep hydrated with a 2-liter water Camelbak® or Platypus® reservoir (not included). Quick-release buckles and internal routing provide easy access.





